

ご利用いただける操作確認済みの端末を掲載しています。

掲載のない端末についてはお問い合わせ先までご連絡ください。

動作確認済み機種

Xi(クロスシイ)	華為技術日本株式会社	d-01H (5.1.1)	d-01K (7.0)				
		d-02H (5.1.1)					
	富士通株式会社	F-01F (4.4.2)	F-01H (5.1.1)	F-01J (6.0.1)	F-01J (7.1.1)		
		F-02F (4.4.2)	F-02G (4.4.4)	F-02H (5.1.1)	F-02H (7.1.1)		
		F-02K (7.1.1)					
		F-03G (4.4.4)	F-03H (7.1.1)				
		F-04G (5.0.2)	F-04H (6.0.1)	F-04H (7.1.1)			
		F-05F (4.4.2)	F-05F (5.0.2)	F-05J (7.1.1)			
	LGElectronics・ジャパン株式会社	L-01J (7.0)	L-01K (8.0)				
		Nexus 5X (8.0)					
	ZTE	MO-01J (6.0.1)	MO-01J (7.1.1)	MO-01K (7.1.1)			
	サムスン電子株式会社	SC-01F (4.3)	SC-01F (4.4.2)	SC-01F (5.0)	SC-01G (4.4.4)		
		SC-01H (5.1.1)	SC-01K (7.1.1)				
		SC-02E (4.3)	SC-02F (4.3)	SC-02F (4.4.2)	SC-02F (5.0)		
		SC-02G (4.4.2)	SC-02G (5.0)	SC-02H (6.0.1)	SC-02H (7.0)		
		SC-02J (7.0)					
		SC-03G (4.4.4)	SC-03G (5.0.2)	SC-03J (7.0)			
		SC-04E (4.3)	SC-04E (4.4.2)	SC-04E (5.0.1)	SC-04F (4.4.2)		
		SC-04F (5.0)	SC-04G (5.0.2)	SC-04G (7.0)	SC-04J (7.0)		
		SC-05G (5.0.2)	SC-05G (7.0)				
		シャープ株式会社	SH-01F (4.4.2)	SH-01G (4.4.4)	SH-01G (5.0.2)	SH-01H (5.1.1)	
			SH-01H (7.0)	SH-01K (7.1.2)			
			SH-02H (5.1.1)	SH-02H (7.0)	SH-02J (7.0)		
	SH-03G (5.0.2)		SH-03G (7.0)	SH-03J (7.1.1)	SH-03J (8.0)		
	SH-04F (4.4.2)		SH-04F (5.0.2)	SH-04G (5.0.2)	SH-04H (7.0)		
	SH-05G (5.0.2)						
	ソニーモバイルコミュニケーションズ株式会社	SH-06F (4.4.2)					
		SO-01F (4.4.2)	SO-01G (4.4.4)	SO-01H (5.1.1)	SO-01H (7.0)		
		SO-01J (7.0)	SO-01K (8.0)				
		SO-02F (4.4.2)	SO-02G (4.4.4)	SO-02H (5.1.1)	SO-02H (7.0)		
		SO-02J (7.0)	SO-02K (8.0)				
		SO-03F (4.4.4)	SO-03F (5.0.2)	SO-03G (5.0.2)	SO-03G (7.0)		
		SO-03H (5.1.1)	SO-03H (7.0)	SO-03J (7.1.1)			
		SO-04F (4.4.2)	SO-04G (5.0.2)	SO-04H (7.0)	SO-04H (8.0)		
		SO-04J (7.1.1)	SO-04J (8.0)				
	SO-05F (4.4.2)	SO-05F (5.0.2)	SO-05G (5.0.2)	SO-05G (7.0)			